

Sandy Springs, GA 30338

OFF-ROAD KIT Installation Instructions



READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE Failure to follow these instructions could result in property damage, bodily injury, or even death.

To Contact Customer Support (706)922-0890 Support@recteq.com

OFF-ROAD KIT CONTENTS

(2) Locking Wheels

Swivel Wheel Assembly and Pull Bar

Pull Bar Handle

Pull Bar Bracket

Pull Bar Base

Hardware Pack

ASSEMBLY INSTRUCTIONS

STEP 1:

Unbox off-road kit from packaging and remove grates, drip pan, and deflector from grill

STEP 2:

With assistance, and using carboard packaging as a protectant, gently lay grill on its back.

Take steps to ensure grill and hopper lid remain closed.

STEP 3:

Remove all four wheels from the underside of the bottom shelf and retain all hardware (bolts, washers, and lock washers)

STEP 4:

Using original wheel hardware, install each individual locking wheel into bottom shelf on the side of the grill that DOES NOT contain a grill pull bar connected to

the barrel



STEP 5:

Using original wheel hardware, install swivel wheel assembly into bottom shelf on the side of the grill that DOES contain a grill pull bar connected to the barrel



STEP 6: With assistance, stand grill upright

STEP 7:Slide off road kit pull bar base onto swivel wheel assembly and insert locking pin



STEP 8:

Using short bolts, washer, lock washer, and nut, install off road kit pull base to off road kit pull bar handle



STEP 9: Using long bolt, large washers, and nut, install pull bar bracket to grill pull bar



STEP 10:

Reinstall deflector, drip pan, and grates into grill



READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE Failure to follow these instructions could result in property damage, bodily injury, or even death.